



2" Gel Pac – Waters for 30 Days

The DRiWATER Gel pac is the perfect choice for vacation or supplemental watering.

Step-by-Step Installation of 2" Gel Pac



1. Water plant thoroughly before applying DRiWATER®.



2. Open Gel Pac by cutting from end to end, pull sides of plastic casing apart to expose entire length of the DRiWATER®. The gel exposed when casing is pulled apart should be approximately 1½" wide @ the center.
 - Do not remove **DRiWATER®** from casing.



3. Place on moist soil surface with opening face down next to the stem of the plant without direct contact with the stem. (It is important that the DRiWATER® touches the soil so liquefaction can begin.) Once the casing is sliced open, the Gel Pac's are pliable and can be molded to fit the shape of the pot.



4. Check plant after 2 weeks. Replace when empty. Enjoy!

Container Size	# of Gel Pacs	Supplemental Watering
4"	1	Installation
6"	1	Installation
8"	2	Installation
10"	3	Installation
12"	4	Installation
14"	5	Installation

Other great DRiWATER® products:



2" Tube & Gel Pac waters for 30-45 days

- Large Indoor Pots
- Outdoor pots
- Hanging Pots



Quart Waters for 90 days

- Vegetable Gardens
- Trees
- Shrubs



PT Delivery System waters for up to 30 days

- Hanging Baskets
- Roses
- Large Pots



Water your poinsettias during the busy holiday season using DR:WATER®

Poinsettia Container Size	# of Gel Pacs	Supplemental Watering
4"	1	15 Days
6"	2	15 Days
8"	3	15 Days
10"	4	15 Days