



PT Delivery System – Waters for 30Days

The PT Delivery System is the perfect choice for watering your hanging baskets.

Step-by-Step Installation of the PT Delivery System



1. Dig a planting hole to the proper depth for the plant.



2. Install the Perforated Tube & Gel Pac as shown.



3. Place your plant or flowers around the outside of the Tube.



4. Fill the pot with soil. Water plant thoroughly.

Container Size	# of Perf. Tube	Supplemental Watering
12"	1	Installation & Weekly
16"	1	Installation & Weekly
1 gallon	1-2	Installation & Weekly
3 gallon	2	Installation & Weekly
5 gallon	2-3	Installation & Weekly
Usage varies according to the requirements of the individual plant.		

Other great DRiWATER® products:



2" Gel Pac waters for up to 30 days

- Indoor Pots
- Hanging Plants
- Poinsettias



2" Tube & Gel Pac waters for 30-45 days

- Large Indoor Pots
- Outdoor pots
- Hanging Pots



Quart waters for up to 90 days

- Vegetable Gardens
- Trees
- Shrubs